


# FloorWarm

# UNDER TILE OWNERS MANUAL





(€

Please visit our website to ensure you have the very latest version of the installation instructions

### **IMPORTANT NOTICE:**

ENSURE THE MAINS SUPPLY IS ISOLATED PRIOR TO INSTALLATION/MAINTANENCE/TESTING

ALL VITREX FLOORWARM UNDERFLOOR HEATING MATS MUST BE EARTHED

A DEDICATED 30Ma (RCD) MUST BE USED WITH THIS HEATING SYSTEM

ELECTRICAL WORK WHICH IS SUBJECT TO PART P BUI LDING REGULATIONS MUST BE CARRIED OUT BY A OUALIFIED ELECTRICAL CONTRACTOR

ALL WORK MUST CONFORM TO BS 7671.2008 AND THE LATEST IEE WIRING REGULATIONS (CURRENTLY 17th EDITION)

CONSULT AN ELECTRICIAN PRIOR TO INSTALLATION TO ENSURE THE ROOM IS SUITABLE FOR UNDERFLOOR HEATING SYSTEMS

#### PLEASE:

**DO** Read all the instructions before commencing installation

**DO** Ensure a 30mA RCD is used in conjunction with the heating system

**DO** Test the system regularly during the installation process

**DO** Take care when planning the layout

**DO** Only cut the mat using scissors, do not use a knife

**DO** Ensure the cables are never less than 50mm apart

**DO** Take care when cutting the mat to prevent accidental damage to the heating cable

**DO** Wear gloves to prevent any irritation from the fibre glass matting

**DO** Ensure a qualified electrician completes the final wiring following the latest electrical regulations

**DO** Purchase slightly less than is required as the mats cannot be shortened in anyway

**DO** Only connect mats in parallel

**DO** Leave a 50mm gap between walls and the heating system

**DO** ensure the floor area is clean and free from any debris. Ensure no protruding nails heads etc.

**DO** use a multi meter to continually test the mat before and during the installation and before laying final flooring

**DO** ensure all electrical connections conform to Part 'P' of the Building Regulations and latest IEE Wiring Regulations

**DO** avoid any unnecessary traffic over the cables during installation

**DO** install thermal and sound insulation materials beneath the heating mats and ensure they are suitable for use with Underfloor Heating systems.

### **PLEASE:**

Do NOT Install the heating system under any fixtures or fittings i.e. bath tub, cabinets & toilets

**Do NOT** Place any heavy items on the matting (e.g. tiles) during the installation

**Do NOT** Cut the heating cable at ANY point

**Do NOT** Overlap the heating mats or cross cables at ANY point

**Do NOT** Install the heating system under any flooring other than tiles

**Do NOT** Leave any excess matting or cable – use a smaller mat if necessary

**Do NOT** Proceed without regular testing of the system

**Do NOT** Start up the system until the adhesive and grout is fully dry

**Do NOT** Connect mats in series

**Do NOT** place items which may prevent the heat rising onto the finish floor, such as heavy rugs, bean bags and solid base furniture. This causes THERMAL BLOCKING and can damage the flooring and heating system

**Do NOT** install the floor sensor close to other heat sources for example hot water pipes

Do NOT install the flooring without final continuity testing of the mats with a multi-meter

# **Installation checklist**

Room plan Insulation Boards Mesh Joint Tape Floorwarm Thermostat Residual Current Device 30 mA (RCD) **Electrical Components:** 

Electrical backbox for thermostat if required Junction box if installing more than one mat Conduit to house power cables

# **Useful tools**

Marker Pen Tape Measure Scissors Electrical screwdrivers & multi meter for connections Gloves

# **Planning your layout**


The mats can be adapted to suit all room shapes and layouts. If using more than one mat ensure that the cold tails reach the thermostat. DO NOT cut the cable.


For difficult areas the mat can be cut away and the cable placed directly onto the insulation board and secured into place using the glass fibre tape.

Connect the mat in parallel, ensuring cold tails reach the thermostat.


# **DIAGRAMS**

### **Layout Example Diagrams**






# **Layout Example Diagrams (cont.)**



# **Typical Wiring System**



### **DISPOSAL OF OBSOLETE APPLIANCES**

**DO NOT** dispose of this appliance in your general waste. Your local authority or retailer will be able to provide further guidance



# **Technical Specification**

### **TECHNICAL INFORMATION**

Construction	Dual conductor wire with earth
Voltage	230V ac – 50Hz
Maximum Load	12W/m
Wire Thickness	Between 2.2m to 2.8mm
Cable Flexibility	Minimum allowable cable radius is 16mm
Power Range	150W to 750W
Approved in accordance with	EN60335 – 1:2004 / EN60335-2-96:2004, EN50366:2003+A1:2006

### **CONSTRUCTION**

Thermal Conductor	2 x resistance wire insulated with FEP tested to 200°C
Outer Insulation	FEP tested to 200°C
IP Rating	IPX7
Reinforcement Mesh	Fibreglass mesh
Fixing Materials	Supplied with 3 rows of double sided tape

### **POWER CONSUMPTION**

	Amps per Square Metre	Watts per Square Metre
1sqm	0.65	150
2sqm	1.30	300
3sqm	1.95	450
4sqm	2.61	600
5sqm	3.26	750

# **Surface Preparation**

The floor must be clean and free from dust and dirt. Remove any old floor coverings.

### Wooden Floors:

Ensure the floor has adequate ventilation underneath

Secure all floorboards to prevent flexing. A secure base is essential for tiled flooring so consider reinforcing with WBP plywood, if necessary.

### Concrete Floors:

Ensure floor is level and structurally sound

# Testing your heating mat

We recommend testing the mat before fully un-wrapping. Test using a multi-meter to ensure continuity through the cables.

Test regularly during the installation process and before laying the final flooring.

# **Insulation**

We recommend the use of insulation boards prior to installing underfloor heating. Insulation increases the performance and efficiency of running underfloor heating. Insulation also reduces the heat up time and reduces running costs.

# **Instructions**

- Ensure the area is clean and free of any debris
- Check the mats visually to ensure they are not damaged. Test the cable using a multi-meter, compare the resistance rating to the following chart. Results should be within +10% / -5% of the following readings:

### Resistance (Ohm) for 230V 150W/m<sup>2</sup>

 1 sqm
 353 Ohm

 2 sqm
 176 Ohm

 3 sqm
 118 Ohm

 4 sqm
 88 Ohm

 5 sqm
 71 Ohm

- Lay the insulation boards, we recommend a brick pattern layout. To cut the boards simply
  run a knife through to score and flex. We recommend using a flexible powder tile adhesive and
  floor adhesive trowel to install the insulation boards. Press firmly into place and once dry, tape
  the edges of the board with Mesh Joint Tape.
- Please take time to re-check your room plan ensuring that adequate space is allowed for any additional fixtures and fittings to be installed post installation.
- Start to lay the mats on the floor, starting close to the thermostat. Mark out any cuts and turns. Mark the position where the temperature sensor is to be positioned.

- If you require a specific layout of cable not offered by the matting, simply cut the matting away and fix the cable in place using the mesh tape. ENSURE THERE IS NEVER LESS THAN 50MM BETWEEN THE CABLES.
- When confident everything is in the correct position, you are ready to install the floor sensor. Place the floor sensor underneath the mat evenly spaced between 2 cables. Prepare a small channel in the insulation board to house the floor sensor. Ensure the channel accommodates the protective tube supplied. Place the floor sensor into the tube; tape over the end this stops the tile adhesive from coming into contact with the sensor. The tip of the sensor should be at least 500mm away from the edge of the wall.
- Fix the mats to the floor using the 3 double sided tape strips (peel off adhesive backing). When cutting and turning the mats take care not to cut the cable.
- Once in place, it is good practice to test the resistance again using a multi meter.
- CONNECTION This must be undertaken by a qualified electrician. This also validates your warranty. Ask your electrician to sign and date your warranty card.
- · Install the thermostat following the instructions supplied.
- As the power cable is thicker than the heating element it may be necessary to cut a channel into the floor to ensure that you maintain an even level.
- Secure the power cables in place using tape.
- Run the power cables and temperature sensor cable to the thermostat using electrical housing if necessary.
- It is possible to shorten or lengthen the cold power cables as necessary. This should only be done by a qualified electrician.
- Test the system again using a multi meter. Write the meter readings on the warranty card to validate.
- Once laid, protect the cables with cardboard to prevent any accidental damage and avoid any unnecessary traffic over the cables, whilst exposed.


# Tiling

- Use a flexible powder tile adhesive which is suitable for underfloor heating systems. Apply following the manufacturer's instructions taking care not to cause any damage to the heating cables. We recommend the use of a plastic adhesive trowel for this purpose.
- Ensure the cables are fully covered with an even layer of adhesive, taking care to avoid any gaps or air pockets.
- Ensure tiles are securely set into adhesive again avoiding any gaps or air pockets.

ADHESIVE AND GROUT MUST BE FULLY DRY BEFORE TURNING ON THE HEATING SYSTEM. This can take a number of days depending on site conditions, temperature and weather.

#### THERMAL BLOCKS - caution must be taken to avoid thermal blocks.

Thermal blocks (increases in temperature at a localised point) are caused when an object placed on the floor prevents the heat generated from being transferred into the air. Thermal blocks can cause damage to the item and / or the flooring. Examples of items that can cause thermal blocks are rubber backed rugs, solid based furniture, floor cushions / beanbags etc.



Ensure a copy of this room layout is displayed at the distribution box



### LIFETIME WARRANTY



### **Products covered by this warranty**

Item No.	Description	Barcode
FWT001	Under Tile 1m <sup>2</sup>	5011204608218
FWT002	Under Tile 2m <sup>2</sup>	5011204608225
FWT003	Under Tile 3m <sup>2</sup>	5011204608232
FWT004	Under Tile 4m <sup>2</sup>	5011204608249
FWT005	Under Tile 5m <sup>2</sup>	5011204608256

Vitrex Floorwarm Underfloor Heating for TILE is covered by a warranty for the LIFETIME of the original floor covering under which it is installed, subject to the terms and conditions set forth herein. The warranty is only applicable to the original purchaser and is not transferable. This warranty is offered by QEP Co. UK Ltd.

During the period of this warranty we will replace free of charge or refund the cost of the product (at our discretion) or arrange for it to be repaired. The cost of repair or replacement is the only remedy under this warranty. This warranty does not extend to costs incurred in relaying, replacing or repairing the floor covering or floor.

This warranty will only be valid if the purchaser promptly registers the product with QEP Co. UK Ltd. To validate the warranty please ensure:

- The product is registered with us within 30 days of purchase. Registration must be completed by filling out the warranty card supplied in the Vitrex Floorwarm Underfloor Heating for TILE pack.
- In the event of a claim, proof of purchase is required so please ensure you retain your receipt or invoice.
- All final electrical connections must be carried out by a qualified electrician to the latest electrical regulations and comply with local
  and national building regulations. The registered electrician must complete the resistance readings on the warranty card and sign it
  stating their Part P Certificate Number.
- The heater must be earthed and protected by 30mA Residual Current Device at all times.

### The warranty becomes invalid if:

- The floor covering installed above the heating mat is damaged, lifted, replaced, repaired or covered with subsequent layers of flooring.
- The heating mat is damaged during installation or by the laying of the floor covering.

As stated in the manual it is important to check the heating mat throughout the installation process and prior to laying the flooring.

Thermostats are warranted for a period of 3 years from the date of purchase, subject to the exclusions set out in this warranty document.

## QEP Co. UK Ltd SHALL IN NO EVENT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO EXTRA UTILITY EXPENSES OR DAMAGES TO PROPERTY.

### QEP Co. UK Ltd is not responsible for:

- Damage or repairs required as a result of faulty installation, incorrect application or misuse
- Damage caused by thermal blocking, details of which are explained in the Owner's Manual
- Damage as a result of floods, fires, wind, lightning, accidents, corrosive atmosphere or other conditions beyond our control
- Use of components or accessories not compatible with this unit
- Products installed outside of the UK
- Regular maintenance, for example cleaning of thermostats
- · Parts not supplied by QEP Co. UK Ltd
- Damage or repairs as a result of improper use, maintenance, operation or servicing
- Failures due to interruption or inadequate power supply
- Changes in the appearance of the product that does not affect its performance
- Any damage caused by frozen or broken water pipes in the event of equipment failure

#### Claims procedure:

Any claim made under this warranty should be made directly to QEP Co. UK Ltd. The claim should be made in a letter stating the following information:

- Product purchased
- Place of purchase
- Date of purchase
- Details of the problem leading to the claim
- Proof of purchase

Please ensure a copy of everything sent is retained. This warranty is offered as an extra benefit and does not affect your statutory rights. The warranty period commences from the date of purchase. Products must be registered within 30 days of purchase. Registration for warranty is confirmed only when a letter of confirmation is sent by QEP Co. UK Ltd.

QEP Co. UK Ltd. Auaust 2010

# Installation, Ownership and Part P Electrical Document

# To validate your warranty you must fully complete this form Owners Name \_\_\_\_\_ Owners address Postcode \_\_\_\_\_\_ Telephone number\_\_\_\_\_\_ Date of purchase \_\_\_\_\_ Owners signature \_\_\_\_\_\_ Date \_\_\_\_\_ Installers Name Installers Telephone Number \_\_\_\_\_ Please state the room in which the heater(s) is installed: ☐ Bathroom ☐ Conservatory ☐ Hall Other Kitchen I confirm that I have read and fully understand the contents of the terms, conditions and installation manual and that the heater(s) has been installed as directed. I confirm that the heater(s) was working prior to tiling and accept that no claim against the manufacturer or its agents can be made for any loss or damage. Installers signature \_\_\_\_\_\_ Date \_\_\_\_\_ Electricians Name Electricians Address \_\_\_\_\_\_ Electricians Phone Number Electricians Part P Certificate Number

### TABLE OF HEATERS INSTALLED

Room	Product Code	Batch No.	Under Tile or Under Wood	RCD Rating	Resistance Reading
Hall	FWT005	12345	Under Tile	30 ma	76.8 ohms

Return completed form to:

Vitrex FloorWarm Warranty, Everest Road, Lytham St. Annes, Lancashire, FY8 3AZ

### WARNING

### Please complete and display this page at your distribution board

This building is fitted with an underfloor heating system utilising 240V ac supply.

Do NOT pierce the flooring above the heating system with nails, screws or other fasteners. (See installation diagram for reference.)

Do NOT expose the floor to thermal blocking or attempt to reduce the area of the heated floor. (Ensure the flooring is suitable for use with the heating system.)

In the event of flooding or when carrying out any repairs or alterations, disconnect the underfloor heating system and contact your electrician or Vitrex Floorwarm Technical Helpline for advice. +44 (0) 1253 789 180.

tails of Installation:
ctricians Name:
mpany Name and Address:
ephone Number:
te:
om with Heating Installed:
al Wattage of System Installed:

### PLEASE LIST THE HEATING MAT INSTALLED AND THE TEST RESULTS

Mat Type	Resistance Rating	Insulaton Test Passed